

# Shed Roof Fitting Instructions

## Materials

- Rubber Sheet
- EPDM Mastic
- Adhesive
- Roller Applicator
- Cartridge Gun
- Knife / Scissors
- Broom (*optional*)



## 1. Prepare the Roof Surface

- Remove the old roofing material and ensure the roof decking is clean, dry, and smooth.
- Check for any damage or weak spots in the decking and repair them

## 2. Measure & Cut the Rubber Membrane

- Measure the roof and cut the EPDM rubber membrane to size, leaving at least 6 inches of overhang on all sides.
- Lay the membrane flat on the roof to let it relax and flatten for about 30 minutes.

## 3. Apply Adhesive

- Fold back half of the membrane and apply rubber roofing adhesive to the exposed decking using a roller.
- Allow the adhesive to become tacky before carefully laying the rubber back down, pressing it firmly to avoid air bubbles.

## 4. Smooth & Secure the Membrane

- Use a broom or roller to smooth out the rubber, working from the center outward to eliminate air bubbles and wrinkles.
- Repeat the process for the other half of the roof.

## 5. Trim Excess Rubber

- Once the membrane is securely in place, trim any excess rubber from the edges using a sharp utility knife.
- Leave enough overhang to cover the roof edge or to secure under the fascia if needed.

## 6. Seal & Finish Edges

- Attach edge trims or use adhesive to seal the edges for a watertight finish.
- Inspect the roof for any areas needing additional adhesive or sealing.