

Ice Vent Pond Heater



ELECTRICAL INSTALLATION

The power supply must meet the specifications on the product. Ice Vent Pond Heater is intended to be used with either a weather-proof cable connector or permanently connected to the fixed wiring in the main system by means of a plug and socket.

The cores in the supply cable are coloured in accordance with the following code:

Brown = Live, Blue = Neutral

If the supply cable is damaged the unit must not be used.

Do not use the supply cable to lift the Ice Vent as this may cause damage.

IMPORTANT: Please note all electrical work on garden lighting and power installations must comply with part P of the building regulations. Failure to comply is a criminal offence. If the installation of this product is not carried out by a competent electrician who is registered under the Part P self-certification scheme then you must notify the local building control department before work begins. For further information and guidance on this matter and other electrical installations in your home that might be covered by the relevant legislation, contact your local authorities building control department.



WARNING - ICE VENT MUST BE USED WITH A RCD

A Residual Current Device (RCD), also known as the Residual Current Circuit Breaker (RCCB), with a tripping current not exceeding 30mA must be installed in the supply circuit.

A means of disconnection from the supply having a contact separation of at least 3mm in all poles must be incorporated in the fixed wiring.

For permanent installations to the mains supply, it is necessary to conform to the regulations of the local electricity authority and this would include the use of a metal or plastic conduit to protect the cable.

Attention has been drawn to the fact that special rules may exist concerning the installation of your Ice Vent (i.e. local building regulations).

Blagdon Affinity Ice Vent must not be used in swimming pools or areas where people are in contact with the water.

Always disconnect the mains electricity supply whilst the equipment is being installed, repaired or maintained. Consult a qualified electrician if in any doubt about wiring this product to the mains supply.



WARNING

Cease use if you drop or damage the unit in any way.

Never run the heater out of water for prolonged periods of time as this may cause irreparable damage.

Do not touch the heater element when running. Avoid contact with pond liner.

IMPORTANT SAFETY INSTRUCTION

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.

WARNING: Disconnect the appliance from the supply when the appliance is not in use and before carrying out maintenance.